

Activ Couch **V2**

Manual guide



Metrics

Producer**VACU ACTIV World Leading
Manufacturer**

Łosino, ul. Modrzewiowa 1
76-251 Kobylnica
POLAND

Poland

+48 059 843 43 43

World Wide

+48 660 216 370

E-mail

contact@vacuactiv.com

**Customer service / Technical
service (ordering spare parts
for machine components):**

www.vacuactiv.com/technical-support/

E-mail

support@vacuactiv.com

Phone

+48 660 216 370

vacuactiv.com

Relaxing rest

A very important element of visit a SPA, wellness or fitness center is a proper rest. After the tension comes relaxation, the body and mind sounds in the same harmonious composition, allowing you to forget about everyday life.

The Aciv Couch is a wonderful relaxing heated lounger with massage function. Warmed to the body temperature and ergonomically fit to the shape of the human body, provide the highest quality comfort. As an extension of the wellness and fitness offer, we offer a modern relaxation couch.

Safety instruction

- do not use the device near water sources (taps, water reservoirs, etc.);
- Do not use a device connected to an extension cord that has not been tested and has no ground;
- Do not use the device if the controller or its cable is damaged or not working properly. In this case, contact the service center;
- if your health condition raises any doubts, consult your doctor before using the product;
- people with a pacemaker, consult a doctor before use;
- do not use the heating option for no longer than 15 minutes in one session. Prolonged use may cause the mat to overheat, which will shorten its useful life;
- do not use the device on places with swelling, inflammation or eczema;
- the use of the device cannot be a substitute for medical care;
- you must not stick needles / pins into the mattress;
- before cleaning, switch off the device, allowing it to cool down;
- device should only be cleaned with a soft sponge.

Remote control

LED lights to indicate the program is running

LED lights to indicate massage strength
LOW / MEDIUM / HIGH

Message zone buttons

Program change button

Activation / deactivation of the heating function

The ON / OFF button turns the device on and off.

Message function
The device equipped with the massage option has three independent levels of massage intensity for each part of the body.

Device specification

Power	
2W (340V, 50Hz)	
Massage	
Number of programs	5
Number of zones	4
Massage strenghts	3 (low, medium, high)
Heating function	
Temperature	36.6°C

Device dimensions FRONT



WIDTH
73,9cm / 29,09 inches

Device dimensions SIDE

HEIGHT**66,8cm / 26,3 inches****LENGTH****210,7cm / 82,95 inches**

VacuActiv | WORLD LEADING
MANUFACTURER

vacuactiv.com